

ESTIMATED INSTALLATION TIMES



The following chart outlines Tommy Gate estimated liftgate installation times by Series and Vehicle Application.

Please note that some installations may take more or less time than estimated. If a liftgate is ordered with a T-64 light kit, a T-54 light kit, or in-frame lights, allow an extra hour for installation time.

APPLICATION	HOURS TO INSTALL
G2 SERIES & ORIGINAL SERIES	
Pickup (500, 1000, 1300, & 1500 lbs.)	4.5 hours
Service & Utility Body (1000, 1300, & 1600 lbs.)	4.5 hours
Flatbed, Stake, & Van (1000,1300, & 1600 lbs.)	6-8 hours
Lift N' Dump (1600 lbs.)	6-8 hours
Cargo Van (1000lbs.)	7-8 hours
TUCKUNDER SERIES	
TKT Models	12 hours
RAILGATE SERIES	
Flatbed, Stake, & Van (1600 & 2000 lbs.)	8 hours
Flatbed, Stake, & Van (2500 & 3000 lbs.)	8 hours
CANTILEVER SERIES	
Cargo Van (1300 lbs.)	12 hours
650 SERIES	
Cargo Van (650 lbs.)	8 hours
V2 SERIES	
Cargo Van (1100 lbs.)	6 hours

Tommy Gate® liftgates are industrial products for material handling only and are not to be used as personnel or wheelchair lifts. For safe handling and operating instructions, visit www.tommygate.com.
 © 2018 Woodbine Manufacturing Company, Inc. All rights reserved.