
Repair Platform Self-Close Arm Kit Instructions 2500/3000 Rail Bifold/GBR Models KIT #14669

These instructions will aid you in replacing the self-close arm on a Tommy Gate 2500-3000lb capacity Bifold or Gas-Bottle-Rack Railgate. Replacing the Self-Close Arm

1. Verify Kit (Figure 1, Table 1).



<u>Table 1</u> : Parts List			
QTY.	PART NO.	DESCRIPTION	
1	14288	Self-Close Arm	
1	14603	Shoulder Bolt	
1	2657	Rubber Handle	
1	14600	Spring Adapter	
1	13624	Spring	
1	553	Flange Lock Nut	

Figure 1: Part Identification.

- 2. Position the platform at a level, comfortable working height.
- 3. Disconnect the #2 power cable from the positive side of the battery or manually Trip the circuit breaker (Figure 2).
- 4. Remove the self-close arm from the platform. The spring and fasteners will not be reused.
- 5. Insert spring adapter into spring (Figure 1).
- 6. Install the new self-close arm and spring using the supplied fasteners (Figure 3).
- 7. Bend the spring over the tab on the self-close arm (Figure 3), using a pair of pliers while holding the self-close arm down firmly. This keeps the spring from contacting the platform.
- 8. Verify that the arm functions smoothly and will clear the ramp when not engaged.

